

# Cx commodore The most realistic voice synthesizer on the market





# **CONTENTS**

11	NTRO	DDUCTION — YOUR COMPUTER TALKS!	1
1	. INS	STALLING YOUR MAGIC VOICETM SPEECH MODULE	2
	1.1.	Using A Television	2
	1.2		
	1.3		
	1.4.		
2.	. MA	KING YOUR COMMODORE 64 TALK	5
	2.1.		
	2.2.		
	2.3.		
	2.4.		
		Counting From 1 to 10	
		SAYing the Alphabet	8
	2.5.		
	2.6.	SAY and Spell1	0
	2.7.	SAYing Numbers	1
	2.8.	Changing the Speech RATE1	2
	2.9.	The RDY Command	3
3.	SUN	MMARY OF BASIC "SPEECH" COMMANDS1	4
	3.1.	The SAY Command1	4
	3.2.	The RATE Command	4
	3.3.	The VOC Command	5
	3.4.	The RDY Command	5
	3.5.	Error Conditions1	5
	3.6.	Discussion	6
ŀ.	PRO	OGRAMMING SPEECH IN ASSEMBLY LANGUAGE1	7
	4.1.	Assembly Language Calling Procedures	8
	4.2.	Memory Requirements	
	4.3.		
		SRESET (Reset Speech System/Stop Talking)	9
		SPSTAT (Get Status of Speech Module)	9
		SAYIT (Say a Word)	

	SAYRAM (Say a Word from RAM)	20
	SPEED (Set Speaking Speed of Synthesizer)	
	SETTAB (Set Look-up Table Address)	20
	SIGNAL (Enable Vectoring to Completion Code)	21
5. AF	PPENDIX	22
	VOCABULARY LIST — BY VOCABULARY NUMBERS	
	VOCABULARY LIST — ALPHABETICAL	

# YOUR COMMODORE COMPUTER TALKS!

Your COMMODORE 64 computer has a VOICE . . . in fact, lots of voices! Whether you're a student, teacher, parent, hobbyist, executive, novice programmer or expert . . . you're going to enjoy your Commodore Magic Voice™ Speech Module.

Here's a short list of the Magic Voice's special features:

- High quality UNDERSTANDABLE speech output
- Includes pre-programmed vocabulary of 235 utterances
- Accepts talking software on cartridge, diskette or tape
- Easily programmed using Commodore BASIC
- Accepts additional vocabularies on diskettes
- Generates speech and music simultaneously
- Generates speech and graphics/animation simultaneously

Your Magic Voice plugs directly into the cartridge port of your COMMODORE 64 or SX-64 Portable Color Computer. You can use diskette, tape or cartridge software (cartridges plug into the Magic Voice's convenient top-loading cartridge port). The Magic Voice will give voice to programs that talk. Most programs that don't include speech operate normally when the Magic Voice is plugged in. However, some older programs may not work. If you have difficulty using a non-speaking program while the module is plugged in, turn off the computer and then remove the module.

The Magic Voice speaks in a pleasant female voice, and has the ability to generate natural sounding human speech using male, female, children's and character voices. The module comes with its own built-in vocabulary of 235 utterances, and you can add thousands of other words using speech-compatible cartridges, diskettes and tapes.

Commodore's "talking" software includes the innovative "MAGIC DESK" series, learning programs like "A Bee C's", and talking games like WIZARD OF WOR and GORF! We've only just begun to explore the educational and recreational opportunities created by talking computers: foreign language training, elementary education, creative strategy games — the possibilities are endless.

If you're a computer programmer, you can use the Magic Voice in your own BASIC or ASSEMBLY LANGUAGE programs! If you develop a program you'd like us to consider as a software product, send a sample to our Software Acquisitions Manager in care of Commodore Software, 1200 Wilson Drive, West Chester, PA 19380.

To find out about new speech-compatible products as they're introduced, see your Commodore dealer, and read Commodore's two computer magazines (POWER/PLAY and COMMODORE).

# 1. INSTALLING YOUR MAGIC VOICE SPEECH MODULE

# 1. Using A Television

It's easy to set up the Magic Voice with your COMMODORE 64 or SX-64 computer. Just follow these simple steps:

- STEP 1: SET UP YOUR COMPUTER for use with television as described in your User's Guide. Do NOT turn it on yet.
- STEP 2: PLUG THE MAGIC VOICE INTO THE CARTRIDGE PORT of your computer.
- STEP 3: LOCATE THE AUDIO CABLE that comes packed with your speech module.
- STEP 4: TAKE THE PHONO PLUG of the cable and PLUG IT INTO THE "AUDIO OUT" SOCKET on the speech module (there are two sockets on the side of the module. The audio in and out sockets are marked on the bottom of the module.
- STEP 5: TAKE THE 5-pin DIN AUDIO/VIDEO CONNECTOR of your AUDIO CABLE and PLUG IT INTO THE AUDIO/VIDEO SOCKET on the computer.
- STEP 6: TURN ON THE TELEVISION SET. TURN THE VOLUME UP.

  (Note: If you're using a speech-compatible cartridge, PLUG IT
  INTO THE CARTRIDGE SLOT on the top of the speech module
  ... DON'T EVER PLUG IN A CARTRIDGE UNLESS YOUR
  COMPUTER IS TURNED OFF!)
- STEP 7: TURN ON THE COMPUTER.

  Note: If you're using pre-recorded software on DISKETTE or TAPE, LOAD the program at this time and RUN it.)
- STEP 8: TEST THE MAGIC VOICE by typing the following exactly as shown (note that to obtain the quotation marks (") around the word HI, you should hold down the SHIFT key and press the 2 key at the same time):

SAY "HI" (and press the RETURN key)

The computer should say "Hi", and you're ready to go. If it does not respond properly, adjust the volume and fine tuning adjustments on your television and try again . . . then consult the TROUBLESHOOTING CHART on Page 4.

\*Note: The Commodore Magic Voice may be used with both the COMMODORE 64 and COMMODORE SX-64 computers, but we refer to COMMODORE 64 throughout the text, since the SX-64 portable computer is compatible with the COMMODORE 64 and works identically when used with the Speech Module.

2. Using A Monitor

Using the Magic Voice with a monitor may yield better sound quality than a television set. Commodore makes a low-priced color monitor which is specially engineered to provide maximum sound and picture quality on Commodore computers. The following steps describe how to use the speech module with Commodore Model 1701/1702 Color Monitor:

- STEP 1: SET UP YOUR COMPUTER for use with MONITOR, as described in your User's Manual. Do NOT turn it on yet.
- STEP 2: PLUG THE MAGIC VOICE INTO THE CARTRIDGE PORT of your computer. The cartridge slot and COMMODORE label on the module must be facing UP.
- STEP 3: Note: you will NOT USE THE AUDIO CABLE that comes packed with your Magic Voice module.
- STEP 4: TAKE the long "TV CABLE" that comes with your COMMODORE 64 (it has identical PHONO PLUGS at each end) and PLUG ONE END INTO THE "AUDIO OUT" SOCKET on the speech module. PLUG THE OTHER END INTO THE "AUDIO" SOCKET on the front righthand corner of your Commodore Model 1701/1702 monitor.
- STEP 5: TAKE THE "MONITOR CABLE" that comes with your Commodore monitor and PLUG THE LARGE AUDIO/VIDEO CONNECTOR INTO THE AUDIO/VIDEO SOCKET on your computer (the AUDIO/VIDEO connector is a round metal plug which has either 5 pins or 8 pins). Plug the VIDEO connector into the "VIDEO" SOCKET on your monitor. Connect the AUDIO PLUG on the monitor cable to the "AUDIO IN" SOCKET on the speech module.
- STEP 6: Steps 6-8 are the same as for a television set (above).

### A Special Note for COMMODORE Color Monitor Owners:

The Commodore Model 1701/1702 Color Monitor has a special capability which can boost the quality even more on your COMMODORE 64 . . . using 3 sockets on the BACK of the monitor labelled "Chroma," Luma" and "Audio." If you have a Commodore 64 with an 8-pin DIN audio/video connector, you can obtain a cable which has an 8-pin DIN connector on one end and 3 phono plugs on the other. You can improve the picture and sound quality by plugging one plug into the CHROMA socket, one plug into the LUMA socket, and the AUDIO plug into the AUDIO socket (you may have to experiment to determine which plug gets the CHROMA and LUMA sockets). When using the MAGIC VOICE with this arrangement, use the "TV Cable" from your COMMODORE 64 to connect the AUDIO OUT socket of the speech module to the AUDIO socket on the back of your Commodore monitor, and connect the AUDIO PLUG on the 8-pin DIN cable into the "AUDIO IN" socket on the speech module.

### 3. Using Your Own Audio System

You can channel the sound output from the Magic Voice through your own audio system, but if you do, remember that the SID CHIP which creates music synthesis and sound effects in the COMMODORE 64 operates SEPARATELY from the Magic Voice. This means if you use a cable to connect the AUDIO OUT socket on the module to the AUDIO IN socket on your audio system, you will need some special cables to connect the audio portion of the signal coming from the computer's music synthesizer. Do this by plugging the "AUDIO OUT" PLUG coming out of the computer into the "AUDIO IN" SOCKET on the speech module.

# 4. Troubleshooting Tips

If you've tried using your Magic Voice and your computer still isn't talking, try these troubleshoting steps:

- 1. Make sure your computer operates normally without the Magic Voice speech module.
- 2. Tune the fine tuning dial on your TV or monitor and go to Step 9.
- 3. Turn up the volume on your television set/monitor/system.
- 4. Turn off the power to your 64 and make sure the cartridge is firmly seated in the expansion slot on your computer.
- Check the audio cable to make sure it's connected to AUDIO OUT and not AUDIO IN.
- 6. If using a TV, make sure the switchbox is set to "computer" and not "TV", and you're tuned to the right channel (Channel 3 or 4. See your Commodore 64 User's Guide).
- 7. Turn the computer OFF and ON and try again.
- 8. If using a Commodore monitor, make sure the "front/rear" selector switch on the back of the monitor is properly set.
- 9. Retype the SAY test command and press the RETURN key. The SAY test command is SAY "HI" < return >.

# 2. MAKING YOUR COMMODORE 64 TALK

#### 1. Your First Words

Type these lines exactly as shown:

SAY"THE" (and press the RETURN key)
SAY"COMMODORE" (and press the RETURN key)
SAY"S" (and press the RETURN key)
SAY"IS" (and press the RETURN key)
SAY"TERRIFIC" (and press the RETURN key)

Your computer has a female voice! Of course, special software can create any type of voice — man, child, cartoon character — even sound effects. One of the first voices created by Commodore's speech technology researchers was the robot voice in the best-selling game WIZARD OF WOR, available on cartridge for the Commodore 64.

As you've seen, you can SAY any of the words in the Magic Voice builtin vocabulary, ONE WORD AT A TIME, if you . . .

- 1. Type the SAY command
- 2. Enclose the word you want to say in QUOTATION MARKS
- 3. Press the RETURN key to activate speech

# 2. Making Plural Words

Let's learn another secret of the Magic Voice — how to make plural words, words that end in "S". Try typing this example exactly as shown:

SAY"COMPUTER":SAY"SSSS" (press the RETURN key)

Did you hear "S" at the end of the word "COMPUTER"? There's a special utterance in the Magic Voice vocabulary which produces an "S" sound for pluralizing words . . . the special utterance is spelled with FOUR "S's".

Before we learn how to write simple computer programs that ''talk'', let's take a quick look at the Magic Voice built-in vocabulary . . .

# 3. Using the Built-in Vocabulary

There are 235 utterances built into the Magic Voice vocabulary, which means you can mix and match a wide range of words and sounds to come up with all types of sentences. Colors, numbers, math words, computer words . . . they're all here. Most of the common words you'll want to use in your programs are included.

Take a look at the alphabetical listing on Page 22. Notice that each word also has a VOCABULARY NUMBER. If you like, you can use the number instead of the word. For example, look at the word "READY" which has the VOCABULARY NUMBER 144. Now try these two examples:

#### SAY"READY" SAY144

(press the RETURN key) (press the RETURN key)

Both examples have the same result. Remember . . . if you SAY an utterance be sure to put it in quotation marks. If you SAY the VOCABULARY NUMBER of the utterance, do not use quotation marks; just type SAY and the number.

# 4. Beginner's Programming Tips — How Basic Programs Work

So far, you've typed all commands DIRECTLY into the computer . . . but a much more efficient way is to type the same commands using a COMPUTER PROGRAM. Computer programs for your COMMODORE 64 are written in the computer language called BASIC, which is built into your Commodore computer.

If this is your first experience with BASIC PROGRAMMING, the following information may help you get started with the examples we're going to explore:

A BASIC program consists of one or more NUMBERED LINES with BASIC commands on each line. Every time you type a number at the far left margin followed by a valid BASIC command, your computer REMEMBERS what you typed and stores that line in its memory. BASIC programs are typically numbered by tens (10, 20, 30 and so on) . . . that's so you can go back later and insert additional lines (11, 12, 13, etc). A BASIC program using the Magic Voice looks like this . . . try typing it:

10 SAY"COMMODORE" (press RETURN) 20 SAY"COMPUTER" (press RETURN) 30 SAY"SSSS" (press RETURN)

Type the word RUN and press the RETURN key to hear the program, then type the word LIST and press RETURN to see the program listed. Here are a few "basic" rules for beginning programmers:

- Always start a program line at the far LEFT (first) column on your screen.
- You must press the RETURN key at the end of each line to enter it into the computer's memory.
- A program actually doesn't start working until you type the word RUN and press the RETURN key. To STOP a program which keeps running, press the RUN/STOP key.
- To view your program lines, type the word LIST and RETURN.
- To erase an entire program, type the word NEW and RETURN.
- To erase one line in a program, type the LINE NUMBER BY ITSELF and press RETURN, or else RETYPE the entire line.
- To edit any line, LIST the program, then move the cursor to the line you want to change, change it and press RETURN.

#### Counting From 1 to 10

If you type the SAY command with a word, the word must be in quotation marks, but if you type the SAY command with the NUMBER of the word, you don't use quotation marks. This NUMBERING feature was included because using numbers allows BASIC programmers to conserve space in their programs. Here's a short example:

10 FORX = 1TO10 (press RETURN) 20 SAYX (press RETURN) 30 NEXT (press RETURN)

Type the word RUN and press the RETURN key. Note that the vocabulary numbers zero to ten are the same as the spoken numbers.

#### **SAYing the Alphabet**

Now type the following line exactly as shown, then type the word RUN and press the RETURN key:

10 FORX = 21TO46 (press RETURN)

This is the same as the counting program, except here we substituted vocabulary numbers 21 to 46, which are the numbers of the letters A through Z.

Well, your computer is starting to talk — but what if you want to create longer sentences? This requires some simple computer programming . . . whether you're a beginner or expert, you'll be surprised how easily you can program speech using the Commodore Magic Voice.

#### 5. Your First Sentences

Here's a little program which speaks a sentence. Type the word NEW and press RETURN to erase your previous program, and type the example as shown:

10 FORX = 1TO5
20 READA\$
30 SAYA\$:NEXT
40 DATACOMMODORE,COMPUTER,SSSS,ARE,TERRIFIC

Type RUN and press RETURN. Is this a terrific sentence? Here's how the program works:

Line 10: A FOR...NEXT loop tells the computer to count from 1 to 5. The NEXT command farther down in the program tells the computer to perform all the actions between the FOR and NEXT commands . . . in this case, READ and SAY 5 words from the DATA statements.

Line 20: READA\$ means look at the DATA in Line 40 and "read" it one item at a time (there are 5 items), all separated by commas.

Line 30: SAYA\$ tells the speech module to speak each item, one item at a time. The NEXT command is the other part of the FOR...NEXT loop. FORX = 1TO5 told the computer to perform the following actions 5 times (READA\$ and SAYA\$ which means READ one item from the DATA statements and SAY that item) and the NEXT command said go back and do it again until the LIMIT (5) is reached.

Line 40: The DATA contained here consists of 5 "words" which together make up the sentence you just programmed. The sentence the computer spoke was: "COMMODORE COMPUTERS ARE TERRIFIC".

Remember that a plural word requires that you add four S's as a separate word, immediately after the word you want to pluralize.

Now type the word NEW and press the RETURN key to erase your previous program.

Here's another example which includes 7 utterances...type this as shown:

10 FORX = 1TO7 (RETURN)
20 READA\$ (RETURN)
30 SAYA\$:NEXT (RETURN)
40 DATAYOUR,COMMODORE,SIX,TY,FOUR,CAN,TALK (RETURN)

Type and RUN this program. (Note if you missed a comma or made another mistake, the computer will give you an ERROR message. LIST your program and retype the line which is wrong.) Here, the sentence reads: "Your Commodore 64 can talk." Did you notice that in LINE 40 we split the word SIXTY into two parts — SIX and TY? This is because our researchers were able to save more space for extra words in our vocabulary by using the "TY" and combining it with FOUR to make FORTY, FIF to make FIFTY, SIX to make SIXTY, SEVEN to make

SEVENTY, and so on . . . otherwise we would need separate words for all of these numbers and you would have fewer words for making sentences. The same applies to numbers in the "teens" — for example, THIRTEEN becomes two separate words: THIR and TEEN.

### 6. SAY and Spell

This little program will show you some general programming tips, as well as how to turn your computer into a SPELLING MACHINE. Type in this program:

10POKE53280,6:POKE53281,0:POKE646,7 20PRINTCHR\$(147)TAB(240) 30PRINT"TYPE A WORD AND PRESS RETURN":INPUTX\$ 40FORY = 1TOLEN(X\$)STEP1:SAYMID\$(X\$,Y,1):NEXT 50GOTO10

Type the word RUN and press the RETURN key, then enter any word (no spaces or numbers) and press the RETURN key. Your COMMODORE 64 will automatically SPELL OUT LOUD the word you typed. The program keeps "looping back" to itself, which means it will keep asking you to type in a word . . . to get out of this "loop", hold down the RUN/STOP key and at the same time, press the RESTORE key. You can always stop a program which is running in this way. The computer will clear itself, BUT YOUR PROGRAM IS STILL IN THE COMPUTER so if you RUN or LIST it, it's still there. Let's see how this program works:

LINE 10 includes 3 POKE commands which change the screen and border colors. POKE 53280 followed by a comma and a number from 0 to 15 will change the BORDER COLOR. POKE 53281 changes the SCREEN COLOR and POKE 646 changes the CHARACTER COLOR. So the first POKE changes the border to blue, the second POKE changes the inside screen to black and last POKE changes the character color to yellow. You can type these POKEs directly into the computer without writing a program. Try experimenting yourself with different color combinations!

LINE 20 clears the screen (PRINTCHR\$(147) is the same as PRINT"CLR/HOME") and TABs 240 spaces from the upper left corner, which just happens to be 6 lines down on your screen — this is used to position the message.

LINE 30 PRINTs the message on the screen. The INPUTX\$ command tells the computer to wait until you type in a word (letters only, no numbers or spaces) and automatically prints a question mark.

LINE 40 uses a FOR...NEXT loop. Remember we said that a FOR...NEXT loop causes all the actions between the FOR and NEXT to be performed, up to the limit of the loop? Here, we start by saying that the loop limits are from 1 (the first letter) up to the LENgth of the word you typed in. LEN(X\$) means the length of the word you type in, which the

computer has defined as "X\$". So if you type a 9-letter word like "COMMODORE", the length of the word is 9 and the loop becomes: FORY = 1TO9. The next portion SAYMID\$(X\$,Y,1) tells the computer which letter to say. X\$ is your word. Y is the position of the letter — it starts with position 1 and changes each time until the "loop" reaches the limit, which is 9, or the LENgth of our word. The number 1 can be considered as a "constant" for the purpose of this discussion.

LINE 50 uses a GOTO statement. This causes the computer to go back to the beginning of the program and start over again at LINE 10.

# 7. SAYing Numbers

The following example gives you a fairly simple way of telling the computer to SAY numbers generated in your program. It doesn't matter whether the numbers being generated come from a student entering the answer to a question, or are being used to repeat a number out loud for an accountant who doesn't have time to look up from a checklist during a calculation . . . whatever the use, it's helpful if the computer is able to speak all numbers up to 999,999,999.

- 5 DIMB%(12)
- 10 FORL = 1T09:READA\$(L):NEXT:FORL = 2T09:READB\$(L):NEXT: FORL = 0T09:READC\$(L):NEXT
- 15 FORL = 1TO2:READD\$(L):NEXT
- 20 POKE53280,6:POKE53281,0:POKE646,7
- 25 PRINTCHR\$(147)TAB(240)
- 30 PRINT"TYPE A NUMBER AND PRESS RETURN":INPUTZ
- 35 IFZ>99999999THEN:SAY"TOO":SAY"LARGE":GOTO25
- 40 IFZ< 999999999THEN:SAY"TOO":SAY"SMALL"GOTO25
- 45 IFZ<OTHEN:SAY"MINUS"
- 50 IFZ = 0THEN:SAY"ZERO":GOTO25
- 55 D = 0:Z\$ = STR\$(Z):RATE(2)
- 60 FORL = LEN(Z\$)TO2STEP 1:B%(D) = VAL(MID\$(Z\$,L,1)): D = D + 1:NEXT
- 65 FORL = INT(D/3)TO0STEP 1:A = B%(L\*3 + 2):B = B%(L\*3 + 1): C = B%(L\*3)
- 70 IFA>0THEN:SAYA\$(A):SAY"HUNDRED"
- 75 IFB>1THEN:SAYB\$(B):IFB\$(B)<>"TWENTY"THEN:SAY"TY"
- 80 IFB = 1THEN:SAYC\$(C):IFC>2THEN:SAY"TEEN"GOTO90
- 85 IFC>0ANDB<>1THEN:SAYA\$(C)
- 90 IFA+B+C>0ANDL>0THEN:SAYD\$(L)
- 95 NEXT:RUN
- 100 DATAONE,TWO,THREE,FOUR,FIVE,SIX,SEVEN,EIGHT,NINE
- 110 DATATWENTY, THIR, FOUR, FIF, SIX, SEVEN, EIGHT, NINE
- 120 DATATEN,ELEVEN,TWELVE,THIR,FOUR,FIF,SIX,SEVEN, EIGHT,NINE
- 130 DATATHOUSAND, MILLION

READY

# 8. The RATE Command — Changing the Talking Speed

You can change the "rate" or speed at which utterances are said, by adding a special command called the RATE command. Here's an example:

- 10 RATE1:SAY"APOSTROPHE"
- 20 RATE4:SAY"APOSTROPHE"
- 30 RATE8:SAY"APOSTROPHE"
- 40 RATE10:SAY"APOSTROPHE"

Type RUN and press RETURN. Did you hear the difference in the rate each number was spoken? The computer talked slower each time. There are 10 RATE settings. RATE1 is the FASTEST speech and RATE 10 is the slowest. RATE4 is standard.

Here's a program that lets you vary the RATE of EACH WORD spoken in a sentence — the RATE settings in the DATA statements cause the utterances which FOLLOW to be spoken at that rate, until a different rate is specified. This is helpful in fine-tuning your programs to provide more natural sounding speech.

- PRINT"CHANGING RATE IN SENTENCE" 10
- 20 **GOSUB 5000**
- PRINT"PRESS ANY KEY FOR ANOTHER PHRASE" 30
- GETAS:IFAS = ""THENGOTO40 40
- 50 GOSUB5000
- SAY"AGAIN":INPUT"AGAIN";A\$ 60
- IFLEFT\$(A\$,1) <> "Y"THENEND 70
- **RESTORE:GOTO10** 80
- 5000 READSP\$
- 5010 IFSP\$="."THENRETURN

gets a word from DATA below if the word is a period then RETURNs above

5020 IFLEFT\$(SP\$.4)="RATE"THENREADSP: RATE(SP):GOTO500 if word is "RATE" -

then READ the next number to set RATE say the word

5030 SAYSP\$

5040 GOTO5000

do it again 5050 DATATHE, COMMODORE, RATE, 1, SIX, TY, FOUR, RATE, 4

5060 DATAIS.TERRIFIC.RATE.6.BECAUSE,RATE,3,NOW

5070 DATAIT, RATE, 2, CAN, RATE, 4, TALK,

5080 DATARATE, 5. THIS. RATE, 3. IS. RATE, 8, GOOD, ...

# 9. Using The RDY Command

Because your COMMODORE 64 has the ability to generate speech simultaneously and independently of music and graphics, sometimes it becomes necessary to tell the computer to wait until speech is completed so that an animation, song or sound effect is properly timed in relation to speech.

Here's a quick example of how you might use the RDY command... first, type the word NEW and press RETURN to erase any previous programs, then type in this program... notice that spoken words and printed words aren't synchronized properly:

- 10 PRINT"THIS":SAY"THIS"
- 20 PRINT"WORD":SAY"WORD"
- 30 PRINT"IS":SAY"IS"
- 40 PRINT"BLUE":SAY"BLUE"

Now type the word NEW and press RETURN, then enter this program:

- 10 IFNOTRDYTHENGOTO10
- 15 PRINT"THIS":SAY"THIS"
- 20 IFNOTRDYTHENGOTO20
- 25 PRINT"WORD":SAY"WORD"
- 30 IFNOTRDYTHENGOTO30
- 35 PRINT"IS":SAY"IS"
- 40 IFNOTRDYTHENGOTO40
- 45 PRINT"BLUE":SAY"BLUE"

The RDY command tells the computer that if NOT READY (in other words, if the computer isn't finished speaking the last word), THEN GOTO the same line and keep going back until the word is finished. Only then does the program drop through to the next command. The RDY command is often used as a NOTRDY condition as shown here. It can be used in a similar way if you are programming simultaneous graphics and speech or music and speech because the computer can process speech, graphics and music simultaneously, which means sometimes you will want the computer to wait until an utterance is completed before proceeding with a song, displaying a graphic symbol, or PRINTing a message on the screen.

# 3. SUMMARY OF BASIC SPEECH COMMANDS

This section describes the Magic Voice program mode from the BASIC language. This feature gives users the ability to write their own games and applications using the Magic Voice preprogrammed vocabulary. Four new commands have been added to Commodore BASIC to make speech easy to use.

#### 1. SAY Command

This command asks the Magic Voice to say a specific word from its preprogrammed vocabulary or additional vocabularies from diskettes, cassettes, and ROM cartridges. The Module accepts either the word number as a numeric expression with a value of 0,...,234; or a BASIC text string spelling out the word to be said. The distinction is made automatically by the module based on the type (string or numeric) of the argument it receives.

#### **Examples:**

SAY"HI"

(Module says "HI")

B\$ = "HI"

SAY B\$

(Module says "HI")

**SAY 21** 

(Module says word #21 in its vocabulary)

X = 21SAY X

SAY(3\*7)

# 2. RATE Command

This command sets the rate or speed at which words and phrases are spoken. Ten speeds are available ranging from 0.65 times slower to 1.4 times faster than the standard rate. The fastest rate is #1, the standard rate is #4, and the slowest rate is #10. The RATE command must be passed a numeric argument.

# Example:

FOR I = 1TO10

RATE(I)

:REM SET SPEED

SAY "ĤI" NEXT I **:REM NOW LISTEN TO IT** 

#### 3. VOC Command

This command alerts the speech module to the presence of an extended vocabulary loaded into system memory. This vocabulary might come from optional disks or cassettes. This command is only needed when additional vocabulary data has been loaded into memory. Look for upcoming additional vocabulary from your Commodore dealer.

#### Example:

LOAD"FISH.VOCAB",8,1

FISH = 32768 :REM ADDRESS OF VOCAB DATA VOC(FISH) :REM TELL SPEECH MODULE SAY"SHARK" :REM MODULE SAYS "SHARK"

#### 4. RDY Command

This command is for use in many advanced applications. It is a logical function which returns the value true if the Magic Voice is ready to accept another SAY command and false if not.

#### Example:

10 IF NOT RDY THEN 10 20 SAY "HI" 30 IF NOT RDY THEN 30 40 SAY "BYE"

This command can also be used by BASIC programs to detect the presence of a speech module in a system. The variable named "RDY" will be zero when a program is LOADed and RUN if a speech module is not present. If the module is present the value of "RDY" will be -1.

#### 5. Error Conditions

The Magic Voice detects and informs the user of certain kinds of errors that it detects. The most common of these occurs when the user tries to "SAY" a word that is not in the module's vocabulary. When this happens, the module will flag an error to BASIC and the message "ILLEGAL QUANTITY ERROR" will appear on the screen.

The module's other functions (RATE & VOC) require numeric arguments. These functions will return the "? TYPE MISMATCH ERROR" message if called with a non-numeric argument.

#### 6. Discussion

This simple command set gives the user the ability to program simultaneous speech output, music, and graphics actions. You may have noticed if you tried any of these examples that the BASIC READY message appears on the screen almost instantly — before the Magic Voice has finished saying what you asked it to say!

This is because the SAY command doesn't actually do the work of generating the speech output. It merely initiates the process by asking the module to start saying a word. Once the SAY command is finished "asking" the module to get started, the module operates independently and execution of our BASIC program continues while the speech is being produced! This is how combined speech, music, and graphics is possible.

The RDY command is included in order for your program to determine what the module is doing at any time. As an example, your program might start with a SAY"HI" and then play a three note tune. If you wanted to play the tune after the word "HI" was finished, you would use the following kind of program:

10 SAY "HI"

20 IF NOT RDY THEN 20

30 GOSUB 1000 : REM SUBROUTINE TO PLAY TUNE AT 1000

Several exciting examples of games that are created easily using these BASIC language commands and the pre-programmed vocabulary are included in this Commodore 64 Magic Voice User's Guide.

# 4. PROGRAMMING SPEECH IN ASSEMBLY LANGUAGE

The Commodore 64 Magic Voice includes a collection of linkage routines necessary to allow user assembly language programs to operate the speech synthesizer. User programs can "say" any of the built-in words and phrases as well as their own specially prepared speech data.

The synthesized signal is brought into the SID chip as an external input and mixed with music generated by the SID. It is important to note that the SID master volume must be turned on in order to hear the synthesized speech. The Magic Voice initializes the SID chip to a volume setting of 15 on power-up. User programs that manipulate the SID volume setting should restore it to 15 before attempting to generate speech output since the built-in talk command software does NOT interact with the SID in any way.

The design philosophy of the assembly language interface is that user access to the speech module occurs via service calls from the user program. Code to handle these service calls is copied into RAM at \$C000-\$C3FF at system power-on. In addition, the core of the speech driver routines and the native vocabulary of the Magic Voice are copied into RAM underneath the BASIC and KERNAL ROMs.

IT IS VERY IMPORTANT NOT TO DISTURB RAM MEMORY LOCATIONS \$A000-\$C3FF AND \$E000-\$FFFF for proper module operation. Programs which load their own speech data and do not rely on the built-in words and phrases of the module must only preserve \$A000-\$A800 and \$C000-\$3FF.

The assembly language interface consists of subroutine calls with the arguments passed in the A and X registers.

There is a separate subroutine for each of the following functions:

- Reset speech module
- · Get speech module status
- Say a word

Detailed functional descriptions and calling specifications are provided below.

## 1. Assembly Language Calling Procedures

Upon power-up the speech module copies certain linkage code into memory locations \$C000 to \$C3FF and then enters a memory mapping mode appropriate to the demands of the cartridge. The cartridge program gains access to the module's programs by JSR'ing to the linkage programs which reside in that RAM area (which is active in all memory map modes).

Where possible, the calling procedures have been designed with ease of use in mind. Functions requiring a single byte except that byte in the processor's A-register. Where two bytes are needed the A-register and the X-register are both used. Only when a count is needed is the Y-register used. Registers are preserved only as indicated in the detailed descriptions below. The conventional uses of the registers are as follows:

A-register: complete operand or low byte if an address is passed.

X-register: upper byte if an address is passed

Y-register: count (0 implies 256).

# 2. Memory Requirements

Use of the speech module impacts the programmer's planning of memory utilization in several ways:

- RAM locations \$C000 thru \$C3FF are used for the linkage code and must NOT be modified by the application program.
- The following zero page locations are used during the voice synthesis process (including NMI processing after speech is initiated).

**\$9B** 

**\$9C** 

**\$A7** 

**\$A8** 

\$BD

\$BE

\$FB

\$FC

\$FD

 The NMI vector needed for voice synthesis is planted in locations \$0318 and \$0319 at the start of the synthesis operation. The original vector is relocated to locations \$0338 and \$0339. This original value is restored when synthesis is complete.

# 3. Assembly Routines

#### SRESET — Reset The Speech System/Stop Talking

**ENTRY: \$C003** 

**ENTRY CONDITIONS: NONE** 

RETURNED INFORMATION: Accumulator is destroyed.

This command resets the synthesizer hardware. It should be included in applications programs for initialization purposes and may be used to stop speech output in mid-utterance.

#### SPSTAT — Get Status Of Speech Module

**ENTRY: \$C006** 

**ENTRY CONDITIONS: NONE** 

RETURNED INFORMATION: ACC = 0 if ready/ - 1 if busy talking.

The N and Z bits of the processor status word are set accordingly. This command may be used to determine whether the speech module has completed previous "sayit" requests and whether a new "sayit" request can be handled immediately.

#### SAYIT — Say A Word

**ENTRY: \$C009** 

ENTRY CONDITIONS: X-reg = most significant portion of the word

number. A-reg = least significant portion.

RETURNED INFORMATION: All registers destroyed.

This command initiates the synthesis of a word or phrase. Control is returned to the calling program almost immediately if the module is not already talking. If the module is talking, then control will not be returned until the current request can be initiated. Words number 0 through 255 are words which are in the speech module. Words number 256 through 4095 are interpreted as located in the user's program space.

CAUTION: Special care should be taken to ensure that no other process in the system that generates NMI's is active when the calls to the speech synthesizer are made. This includes the RS-232 channel and the serial bus devices. The RS-232 channel is the only channel which must actually be CLOSED. The serial bus channels may be open and may be left opened, but must not actively transmit data. It is recommended that programs which wish to perform series use I/O check, via SPSTAT to ensure that speech output is complete before initiating the operations.

#### SAYRAM — Say A Word From RAM.

**ENTRY: \$C00C** 

ENTRY CONDITIONS: X-reg = most significant portion of the word

number. A-reg = least significant portion.

RETURNED INFORMATION: All registers destroyed.

This command is similar to the "SAYIT" except that the structure permitting access through the memory mapping system is bypassed. This entry point is intended to permit generation of speech from RAM based speech data. This may also be useful if RAM versions of words are modified under program control.

Speech is generated as in the SAYIT command above. Utterances 0...255 are taken from the on-board vocabulary and utterances 256...4095 are taken from memory as established by the SETTAB routine. No mapping is performed. Speech data is taken directly from the program's address space.

NOTE: See caution under SAYIT above.

#### SPEED — Set Speaking Speed Of Synthesizer

**ENTRY: \$C00F** 

ENTRY CONDITIONS: A-reg = desired speed code from 1...10.

RETURNED INFORMATION: No register affected.

The SPEED capability is used to speed up or slow down the speaking rate of the synthesizer. The range of speed variations is from .65X decrease in the speed (speed code = 10) to a 1.4X increase (speed code = 1) Normal speed is speed code 4.

## **SETTAB** — Set Utterance Look Up Table Address

**ENTRY: \$C012** 

ENTRY CONDITIONS: A-reg = lower byte of address. X-reg = upper

byte of address.

RETURNED INFORMATION: None.

The SETTAB function is used to tell the speech module the starting memory address of user supplied speech data. It is identical to the BASIC VOC command. This command MUST be employed prior to any attempts to generate speech with utterance numbers greater than 255.

#### SIGNAL — Enable Vectoring To Completion Code

**ENTRY: \$C015** 

ENTRY CONDITIONS: JMP instruction to completion code handling routine MUST be planted in memory locations \$C018-\$C01A

RETURNED INFORMATION: None.

This function is for support of advanced applications which implement asynchronous event driven programming techniques. The effect of the SIGNAL call is to increment a counting semaphore maintained by the talking process. This semaphore is waited on by the speech completion, which when signalled, will jump to the completion code vector address (\$C018). Users should plant a JMP instruction in the three bytes of memory starting at this address. ONLY \$C018-\$C01A SHOULD BE CHANGED.

This JMP instruction should point into user code which handles the completion of the speech output event. The user completion routine MUST terminate with an RTS instruction. Completion code handlers may be used for a variety of purposes but, in general, should be kept short since IRQ's are disabled and NMI's are ignored during this time.

NOTE: This facility also provides a means for user programs to detect the presence or absence of a speech module: a power-up footprint. The completor code vector area (\$C018-\$C01A) is initialized on power-up to the instruction sequence:

\$C018 NOP \$C019 NOP \$C01A RTS

These instructions correspond to the values \$EA, \$EA, \$60. User programs may detect the presence of a module by verifying that these locations contain the given values.

# 5. APPENDIX

# 1. Resident Vocabulary

The Magic Voice contains a built-in vocabulary of 235 utterances in a female voice. The utterances are numbers 0 to 234. The following is a numerical listing of the utterances contained in the Commodore 64 Magic Voice.


2         TWO         43         W         84         COMMODORE           3         THREE         44         X         85         END           4         FOUR         45         Y         86         POINT           5         FIVE         46         Z         87         THING           6         SIX         47         (SILENCE)         88         QUESTION           7         SEVEN         48         ADD         89         TURN           8         EIGHT         49         SUBTRACT         90         AM           9         NINE         50         DIVIDE         91         ARE           10         TEN         51         DIVIDED         92         BE           11         ELEVEN         52         EQUALS         93         BUY           12         TWELVE         53         LESS         94         CAN           13         THIR         54         MINUS         95         CORRECT           14         FIF         55         MORE         96         DID           15         TWENTY         56         NUMBER         97         DO	0	ZERO	41	U.	82	YOU'RE
3       THREE       44       X       85       END         4       FOUR       45       Y       86       POINT         5       FIVE       46       Z       87       THING         6       SIX       47       (SILENCE)       88       QUESTION         7       SEVEN       48       ADD       89       TURN         8       EIGHT       49       SUBTRACT       90       AM         9       NINE       50       DIVIDE       91       ARE         10       TEN       51       DIVIDED       92       BE         11       ELEVEN       52       EQUALS       93       BUY         12       TWELVE       53       LESS       94       CAN         13       THIR       54       MINUS       95       CORRECT         14       FIF       55       MORE       96       DID         15       TWENTY       56       NUMBER       97       DO         16       HUNDRED       57       PLUS       98       DOES         17       THOUSAND       58       REMAINDER       99       DONE         18	1	ONE	42	V	83	ANSWER
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	2	TUDEE				
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	3	IHKEE				
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	4	FOUR				
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	5	FIVE		Z (211 51105)		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	6	SIX				
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		SEVEN		ADD		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		EIGHT		SUBTRACT		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		NINE		DIVIDE		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		TEN		DIVIDED		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		ELEVEN		EQUALS		
13 THIR 54 MINUS 95 CORRECT 14 FIF 55 MORE 96 DID 15 TWENTY 56 NUMBER 97 DO 16 HUNDRED 57 PLUS 98 DOES 17 THOUSAND 58 REMAINDER 99 DONE 18 MILLION 59 IT 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		TWELVE		LESS		
18 MILLION 59 11 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		IHIK		MINUS		
18 MILLION 59 II 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		FIF		MORE		
18 MILLION 59 II 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	15			NUMBER	97	DO
18 MILLION 59 11 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR		HUNDRED	57	PLUS	98	
18 MILLION 59 II 100 FIND 19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR	17	THOUSAND		REMAINDER	99	DONE
19 TEEN 60 AT 101 GET 20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR 22 B 63 TIMES 104 HELP 23 C 64 APOSTROPHE 105 IS 24 D 65 WORD 106 KNOW 25 E 66 ER 107 LIKE 26 F 67 EST 108 PRESENTS 27 G 68 ING 109 READ 28 H 69 SSSS 110 SAY 29 I 70 TH 111 SEE 30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH	18	MILLION	59	IT	100	
20 TY 61 WHEN 102 HAVE 21 A 62 HAS 103 HEAR 22 B 63 TIMES 104 HELP 23 C 64 APOSTROPHE 105 IS 24 D 65 WORD 106 KNOW 25 E 66 ER 107 LIKE 26 F 67 EST 108 PRESENTS 27 G 68 ING 109 READ 28 H 69 SSSS 110 SAY 29 I 70 TH 111 SEE 30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW	19	TEEN	60	AT	101	GET
21 A       62 HAS       103 HEAR         22 B       63 TIMES       104 HELP         23 C       64 APOSTROPHE       105 IS         24 D       65 WORD       106 KNOW         25 E       66 ER       107 LIKE         26 F       67 EST       108 PRESENTS         27 G       68 ING       109 READ         28 H       69 SSSS       110 SAY         29 I       70 TH       111 SEE         30 J       71 ALL       112 START         31 K       72 ME       113 USE         32 L       73 MY       114 WAIT         33 M       74 THAT       115 WANT         34 N       75 THEIR       116 WAS         35 O       76 THEY'RE       117 WON         36 P       77 THIS       118 WRITE         37 Q       78 WHAT       119 HERE         38 R       79 WHICH       120 HIGH         39 S       80 WHO       121 HOW	20	TY	61	WHEN	102	HAVE
22 B       63 TIMES       104 HELP         23 C       64 APOSTROPHE       105 IS         24 D       65 WORD       106 KNOW         25 E       66 ER       107 LIKE         26 F       67 EST       108 PRESENTS         27 G       68 ING       109 READ         28 H       69 SSSS       110 SAY         29 I       70 TH       111 SEE         30 J       71 ALL       112 START         31 K       72 ME       113 USE         32 L       73 MY       114 WAIT         33 M       74 THAT       115 WANT         34 N       75 THEIR       116 WAS         35 O       76 THEY'RE       117 WON         36 P       77 THIS       118 WRITE         37 Q       78 WHAT       119 HERE         38 R       79 WHICH       120 HIGH         39 S       80 WHO       121 HOW	21	Α	62	HAS	103	HEAR
23       C       64       APOSTROPHE       105       IS         24       D       65       WORD       106       KNOW         25       E       66       ER       107       LIKE         26       F       67       EST       108       PRESENTS         27       G       68       ING       109       READ         28       H       69       SSSS       110       SAY         29       I       70       TH       111       SEE         30       J       71       ALL       112       START         31       K       72       ME       113       USE         32       L       73       MY       114       WAIT         33       M       74       THAT       115       WANT         34       N       75       THEIR       116       WAS         35       O       76       THEY'RE       117       WON         36       P       77       THIS       118       WRITE         37       Q       78       WHAT       119       HERE         38       R       79 <td< td=""><td>22</td><td>В</td><td>63</td><td>TIMES</td><td>104</td><td>HELP</td></td<>	22	В	63	TIMES	104	HELP
24       D       65       WORD       106       KNOW         25       E       66       ER       107       LIKE         26       F       67       EST       108       PRESENTS         27       G       68       ING       109       READ         28       H       69       SSSS       110       SAY         29       I       70       TH       111       SEE         30       J       71       ALL       112       START         31       K       72       ME       113       USE         32       L       73       MY       114       WAIT         33       M       74       THAT       115       WANT         34       N       75       THEIR       116       WAS         35       O       76       THEY'RE       117       WON         36       P       77       THIS       118       WRITE         37       Q       78       WHAT       119       HERE         38       R       79       WHICH       120       HIGH         39       S       80       WH	23	С	64	APOSTROPHE	105	IS
25 E 66 ER 107 LIKE 26 F 67 EST 108 PRESENTS 27 G 68 ING 109 READ 28 H 69 SSSS 110 SAY 29 I 70 TH 111 SEE 30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW	24	D	65	WORD	106	KNOW
26       F       67       EST       108       PRESENTS         27       G       68       ING       109       READ         28       H       69       SSSS       110       SAY         29       I       70       TH       111       SEE         30       J       71       ALL       112       START         31       K       72       ME       113       USE         32       L       73       MY       114       WAIT         33       M       74       THAT       115       WANT         34       N       75       THEIR       116       WAS         35       O       76       THEY'RE       117       WON         36       P       77       THIS       118       WRITE         37       Q       78       WHAT       119       HERE         38       R       79       WHICH       120       HIGH         39       S       80       WHO       121       HOW	25	E	66	ER	107	LIKE
27 G       68 ING       109 READ         28 H       69 SSSS       110 SAY         29 I       70 TH       111 SEE         30 J       71 ALL       112 START         31 K       72 ME       113 USE         32 L       73 MY       114 WAIT         33 M       74 THAT       115 WANT         34 N       75 THEIR       116 WAS         35 O       76 THEY'RE       117 WON         36 P       77 THIS       118 WRITE         37 Q       78 WHAT       119 HERE         38 R       79 WHICH       120 HIGH         39 S       80 WHO       121 HOW         40 THERE			67	EST	108	PRESENTS
28 H 69 SSSS 110 SAY 29 I 70 TH 111 SEE 30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW			68	ING	109	
29 I 70 TH 111 SEE 30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW			69	SSSS	110	SAY
30 J 71 ALL 112 START 31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW			70	TH	111	
31 K 72 ME 113 USE 32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW			71	ALL	112	START
32 L 73 MY 114 WAIT 33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				ME	113	
33 M 74 THAT 115 WANT 34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				MY	114	
34 N 75 THEIR 116 WAS 35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				THAT	115	
35 O 76 THEY'RE 117 WON 36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				THEIR	116	
36 P 77 THIS 118 WRITE 37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				THEY'RE	117	
37 Q 78 WHAT 119 HERE 38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW				THIS	118	
38 R 79 WHICH 120 HIGH 39 S 80 WHO 121 HOW		= -		WHAT	119	
39 S 80 WHO 121 HOW				WHICH	120	
40 TUEF				WHO	121	
40 I 81 YOUR 122 IHERE	40	Ť	81	YOUR	122	THERE

# 2. Alphabetical List Of Words

		_	
Α	21	E	25
ADD	48	EACH	170
AFTER	162	EIGHT	8
AGAIN	175	ELEVEN	11
ALL	71	END	85
AM	90	ENTER	171
	127	EQUALS	52
AN			
AND	128	ER	66
ANSWER	83	ERROR	172
ANY	169	EST	67
		EVERY	174
APOSTROPHE	64		
ARE	91	F	26
AS	129	FIF	14
AT	60	FIND	100
В	22	FIRST	181
BAD	158	FIVE	5
BE	92	FOR	132
BECAUSE	164	FOUR	4
BLACK	185	FROM	133
BLUE	191	G	27
BROWN	194	GAME	218
BUT	130	GET	101
BUY	93	GIVE	203
BY	131	GOOD	159
BYE	153	GREEN	190
С	23	GREY	195
CAN	94	Н	28
COLOR	184	HAS	62
COME	202	HAVE	102
COMMAND	212	HE	197
COMMODORE	84	HEAR	103
COMPUTER	213	HELP	104
CONTROL	214	HERE	119
		HI	154
CORRECT	95		
CURSOR	215	HIGH	120
CYAN	188	HOUR	234
D	24	HOW	121
DARK	211	HUNDRED	16
DID	96	!	29
DISK	216	IF	134
DIVIDE	50	IN	135
DIVIDED	51	ING	68
		IS	105
DO	97		
DOES	98	ΙŢ	59
DONE	99	J	30
DOWN	217		

K KEY KNOW L LARGE LEFT LESS LETTER LIGHT LIKE LOAD MANY ME MINUS MORE MOST MY N NAME NOT NOW NUMBER O OF OF OH ONE OR OR OR OR ONE OR ONE OR ONE	31 219 106 32 136 220 53 180 196 107 221 33 173 209 72 18 54 55 163 73 4 222 137 9 165 138 176 35 139 140 141 142 1 143 198 198 198 210 210 211 211 211 211 211 211 211 211	Q QUESTION R READ READY RED REMAINDER RIGHT RUN S SAME SAVE SAY SECOND SEE SEVEN SHE (SILENCE) SIX SMALL SORRY SSSS START STOP SUBTRACT SYMBOL T TAKE TALK TAPE TEEN TEN TERN TEN THAN THANK THAT THE THEIR	37 88 38 109 144 187 58 226 227 39 145 228 110 182 111 167 205 7 199 47 6 177 160 69 12 29 49 230 40 206 158 178 199 199 199 199 199 199 199 199 199 19
POINT	86	THERE THEY'RE	122 76
			• •

THREE	3
THUH	148
TIMES	63 150
TO TOO	123
TRY	179
TURN	89
TWELVE	12
TWENTY	15
TWO	2
TY	20
U	41
UH	126
UNTIL	208
UP	232
USE	113
VEDY	42
VERY W	152 43
WAIT	114
WANT	115
WAS	116
WE	200
WEIGHT	233
WERE	207
WHAT	78
WHEN	61
WHERE WHICH	124 79
WHITE	186
WHO	80
WHY	125
WITH	151
WON	117
WORD	65
WRITE	118
WRONG	161
X Y	44 45
YELLOW	45 192
YES	157
YOU	201
YOU'RE	82
YOUR	81
Z	46
ZERO	0





Commodore Business Machines, Inc. 1200 Wilson Drive • West Chester, PA 19380

Commodore Business Machines, Limited 3370 Pharmacy Avenue • Agincourt, Ontario, M1W 2K4